

## Component Locations

[G131 – Oxygen sensor \(O2S\) 2. behind Three Way Catalytic Converter \(TWC\) \(2.8 ltr. engine\)](#)

[G131 – Oxygen Sensor \(O2S\) 2 Behind Three Way Catalytic Converter \(TWC\) \(4.0 ltr. engine\)](#)