

Component Locations

[N128 – Ignition coil 2 \(1.8 ltr. engine\)](#)

[N128 – Ignition coil 2 \(2.8 ltr. engine\)](#)