



**G28 Engine Speed (RPM) Sensor (2.0 ltr. tdi engine)**

- on driver's side of cylinder block, near transmission flange