



**G38 Transmission Vehicle Speed Sensor (VSS)**

- inside transmission, on valve body