



G42 Intake Air Temperature (IAT) sensor (2.8 ltr. engine)

- in engine compartment, in intake air duct at rear of intake manifold