



G42 Intake Air Temperature (IAT) Sensor (2.0 ltr. tdi engine)

- in engine compartment, on intake air duct behind engine
- integral with –G31–