



**S116 Fuse for injectors**

- inside E-box